

Modern Aire Ventilating

7319 Lankershim Blvd | North Hollywood, CA 91605 Office: (818) 765-9870



Filter Installation Instructions

Do not install filters until the canopy is in the hanging position

Step 1

- Locate Filler Panels and Baffle Filters (two fillers one left, one right and multiple filters depending on width of canopy)
- Place filler panels and baffle filters on a flat surface as pictured with the filler panels bent edges against the filters edge as pictured. (height will match)
- Remove PVC protective coating from filler panels.

Step 2

- Install filler panels on left and right side of ventilation canopy.
- Filler panels install on top of the angled edge as pictured.



Step 3

- Install Baffle Filters against filler panel starting on the left and right side working toward the center of the canopy.
- Place the filter inside the canopy towards the inside front of the canopy.
- Place the bottom of the filter down into the lower receiving tray.
- Allow the top of the filter to rest on top of the light bar.

Questions or Concerns: Please feel free to contact us directly at
(818) 765-9870

Modern Aire Ventilating

7319 Lankershim Blvd | North Hollywood, CA 91605 Office: (818) 765-9870

