

Modern Aire Ventilating

7319 Lankershim Blvd | North Hollywood, CA 91605 Office: (818) 765-9870



Replacing The Light Switch

IMPORTANT Step 1: CUT POWER TO HOOD!



STEP 2:

Remove filter.



STEP 3:

Unscrew knob with $\frac{1}{8}$ th inch slot screw driver.



STEP 4:

With a 10mm nut driver, remove the switch from the panel.



STEP 5:

Reach behind the panel and pull out the light switch.



STEP 6:

Cut wires to switch.



STEP 7:

Connect wires from switch to hood. Either switch can be connected to either hood wire.



Step 8:

Put switch back into opening.



Step 9:

Tighten nut back on switch.



Step 10:

Screw knob back on.



Step 11:

Put filters back into place.

Modern Aire Ventilating

7319 Lankershim Blvd | North Hollywood, CA 91605 Office: (818) 765-9870

